



Flow Control Maintains Room dP via Offset
 Example:
 1200 cfm SUPPLY
 - 1100 cfm EXHAUST

 100 cfm OVERSUPPLY
 (room is positive pressure)

BEFORE ECM
 LAB WITH HOOD

DISCLAIMER: This drawing was prepared and is presented for communication purposes only and to aid building occupants in gaining a conceptual understanding of the revised systems. This drawing is in no way an engineering document or a part of the project design.

DRAWN BY	P. DAVIDS
REV 2	DATE 08-OCT-2013